



Computer Familiarization

Section 5

Power ON button

Wireless On/Off Button

Delete Key


Control "Ctrl" Key

Touch Pad


Left Click Button
(for action)
Click and hold to drag

Space Bar

Right Click Button
(for options)




Laptop Left Side



**Camera
USB Plug**

**Printer USB
Plug**

Laptop Back



Power Cord Plug

Network Cord Plug

Extra USB port